

ROOMETTES

BORGO AUTO LOANS #01-202-01 AND COMBO R4383

INSTRUCTIONS

1. REMOVE THE STOREFRONT FROM THE CARDS TOCK SHEET WITH A SHARP HOBBY KNIFE. **DO NOT CUT THE DOTTED LINES.** THEY ARE FOR FOLDING.
2. CAREFULLY BEND THE WALLS, FLOOR AND CEILING INWARD TO CREATE A BOX. **DO NOT OVERBEND THEM!**
3. BEND AND GLUE THE LEFT AND RIGHT WING TABS UNDER THE FLOOR. USE A POPSICLE STICK OR SIMILAR TOOL TO CAREFULLY APPLY PRESSURE ON THE FLOOR OVER EACH WING TO SET THE GLUE.
4. FLIP THE ROOM OVER AND GLUE THE LEFT AND RIGHT WING TABS OVER THE TOP OF THE CEILING.
5. BEND THE TABS LABELLED "BEND UP" AT A RIGHT ANGLE. SET THE ROOM ASIDE TO DRY.
6. ASSEMBLE THE OTHER ROOMS IN A SIMILAR MANNER.
7. DEPENDING ON THE PLACEMENT OF THE ROOMS YOU MAY FIND IT NECESSARY TO REMOVE SOME OF THE PLASTIC MATERIAL AROUND THE WINDOWS INSIDE THE BUILDING TO GET THEM TO FIT. AS AN ALTERNATIVE, YOU CAN CUT THE WALL OF THE ROOM TO FIT AROUND THE WINDOW INSTEAD.
8. CHECK ALL GLUE JOINTS TO MAKE SURE THEY ARE SOLID BEFORE PROCEEDING. TEST FIT THE ROOMS. IF YOU HAVE ASSEMBLED YOUR BUILDING ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS THEY SHOULD FIT EASILY. IF YOU FIND THEY FIT TOO TIGHT VERTICALLY YOU CAN REMOVE SOME OF THE WALL-MOUNT TAB MATERIAL WITH SCISSORS FOR ADDITIONAL CLEARANCE.
9. TO PREVENT LIGHT LEAKAGE, SPREAD A BIT OF GLUE INTO THE PERFORATED SEAMS ON THE CORNERS OF THE ROOM FROM THE OUTSIDE. THIS WILL ALSO MAKE THE JOINTS STRONGER.
10. USE YOUR KNIFE TO REMOVE THE CEILING PLUGS AND INSTALL PROVIDED LEDS, FASTENING THEM IN PLACE WITH GOOD QUALITY TAPE OR GLUE.
11. STARTING WITH THE UPPER FLOOR GLUE THE ROOMS TO THE WALLS, BEING CAREFUL NOT TO GET GLUE ON YOUR CLEAR WINDOW MATERIAL.
12. PLUG THE LED HARNESS INTO YOUR WOODLAND SCENICS® JUST PLUG® OR NCE ILLUMINATOR MODULE. DIM THE LEDS, SIT BACK AND ENJOY YOUR EFFORTS!

TIP: CITY CLASSICS' STOREFRONT SIGN KIT #850 INCLUDES A SIGN FOR BORGO AUTO LOANS FOR THE OUTSIDE OF YOUR BUILDING.

THIS IS NOT A TOY.
NOT SUITABLE FOR CHILDREN
UNDER 14 YEARS OF AGE.